

▶ DESIGN - LED LINEAR HIGH BAY WITH Q-BASE is extremely efficient with up to 170lm/W output. It has a built-in motion sensor base, allowing you to install the microwave motion or PIR sensor. Die-cast aluminum housing with excellent heat dissipation along with an anti-glare PC lens provide many years of use. It is designed to operate on 120-277V or 277-480V circuits with a 0-10V dimmable driver.

▶ SURGE PROTECTION - 6kV protects the fixture from voltage spikes and current surges.

COLOR AND POWER SELECTABLE - You can choose either a 3,500K neutral white, 4,000K cool white or 5,000K daylight color temperature, and change the power with a simple switch.

▶ BATTERY BACK-UP - The built-in battery back-up provides 90 minutes of power in case of emergency.

▶ INSTALLATION - This fixture has three different mounting options: suspended, surface, and pendant.

▶ APPLICATION - Perfect commercial or industrial solution for warehouses, supermarkets, retail stores, gyms, and many other applications. This fixture has IK10 level impact protection and is also Damp Locations rated.

▶ ADVANTAGES - With calculated lifespan up to 167,000 hours, these fixtures are made to last decades under normal operation! ASD provides a 5-year limited warranty along with UL and DLC Premium certifications to guarantee top quality products and safety!

Catalog number	
Notes	
Туре	





PRODUCT PRESENTATION:

Model	Power	Sensor base	Voltage	Dimming	Lumens	CCT	Finish	Dimensions	Certification
WHB5B 150lm/W									
ASD-WHB5B-100A50	60/80/100W	3-pin	120-277 V	0-10 V	up to 15,386 lm	5,000 K	White	14-15/16" x 9-13/16" x 2-15/16"	UL (E473804), DLC
ASD-WHB5B-160A50	100/130/160W	3-pin	120-277 V	0-10 V	up to 24,842 lm	5,000 K	White	14-15/16" x 9-13/16" x 2-15/16"	UL (E473804), DLC
ASD-WHB5B-220A50	130/160/220W	3-pin	120-277 V	0-10 V	up to 35,342 lm	5,000 K	White	17-11/16" x 12-7/16" x 2-15/16"	UL (E473804), DLC
ASD-WHB5B-320A50	160/220/320W	3-pin	120-277 V	0-10 V	up to 50,848 lm	5,000 K	White	20-1/2" x 14-7/16" x 3-1/4"	UL (E473804), DLC
ASD-WHB5B-500A50	320/400/500W	3-pin	120-277 V	0-10 V	up to 75,905 lm	5,000 K	White	35-1/2" x 12-7/16" x 2-15/16"	UL (E473804), DLC
WHB58-CP 150lm/W +10ft CORD WITH PLUG									
ASD-WHB5B-160A50-CP	100/130/160W	3-pin	120-277 V	0-10 V	up to 24,842 lm	5,000 K	White	14-15/16" x 9-13/16" x 2-15/16"	UL (E473804), DLC
ASD-WHB5B-220A50-CP	130/160/220W	3-pin	120-277 V	0-10 V	up to 35,342 lm	5,000 K	White	17-11/16" x 12-7/16" x 2-15/16"	UL (E473804), DLC
				SENSORS	S AND REMOTE				
ASD-09MW-WH	Microwave motion	n sensor 3pin whit	е					2-1/8" x 2-1/8" x 1-5/16"	-
ASD-09MW-BK	Microwave motion	n sensor 3pin black	<					2-1/8" x 2-1/8" x 1-5/16"	-
ASD-09IR-WH	Infrared motion se	ensor 3pin 39 ft wh	iite					2-1/8" x 2-1/8" x 1-11/16"	-
ASD-09IR-BK	Infrared motion se	ensor 3pin 39 ft bla	ck					2-1/8" x 2-1/8" x 1-11/16"	-
ASD-09IR50-WH	Infrared motion se	ensor 3pin 50 ft wh	ite					2-1/8" x 2-1/8" x 1-11/16"	-
ASD-06RC	Remote control fo	r motion sensor						5-11/16" x 1-3/4" x 13/16"	-
ASD-09MW-NLS-WH	Microwave motion	n sensor smart 3pi	in white					2-1/8" x 2-1/8" x 1-3/8"	-
ASD-09IR-NLS-WH Infrared motion sensor smart 3pin 39 ft white								2-1/8" x 2-1/8" x 1-11/16"	-

For detailed luminous flux information please refer to Annex 1, page 10.

For most up-to-date spec sheets please refer to asd-lighting.com

(UL)





TECHNICAL PARAMETERS:

Model	Max input current	Inrush current	Work environment Operating temperature		Power factor	Surge protection	Housing	Lens	CRI
WHB5B 150lm/W									
ASD-WHB5B-100A50	1.3 A	80 A	Damp location	-40°F to 122°F (-40°C to 50°C)	> 0,9	6 kV	Aliminum	PC	> 80
ASD-WHB5B-160A50	2 A	80 A	Damp location	-40°F to 122°F (-40°C to 50°C)	> 0,9	6 kV	Aliminum	PC	> 80
ASD-WHB5B-220A50	2.6 A	80 A	Damp location	-40°F to 122°F (-40°C to 50°C)	> 0,9	6 kV	Aliminum	PC	> 80
ASD-WHB5B-320A50	4 A	100 A	Damp location	-40°F to 122°F (-40°C to 50°C)	> 0,9	6 kV	Aliminum	PC	> 80
ASD-WHB5B-500A50	6 A	80 A	Damp location	-40°F to 122°F (-40°C to 50°C)	> 0,9	6 kV	Aliminum	PC	> 80
			WHB5B-CP 150lm/W	/ +10ft CORD WITH PLUG					
ASD-WHB5B-160A50-CP	2 A	80 A	Damp location	-40°F to 122°F (-40°C to 50°C)	> 0,9	6 kV	Aliminum	PC	> 80
ASD-WHB5B-220A50-CP	2.6 A	80 A	Damp location	-40°F to 122°F (-40°C to 50°C)	> 0,9	6 kV	Aliminum	PC	> 80

DIMMING COMPATIBLE CONTROLS:


Dialia		Leviton
Models D	VSTV-453P	IP710-LFZ

PACKAGE CONTENTS:





ACCESSORIES (sold separately):



ACCESSORY COMPATIBILITY LIST:

Models	Accessories	Microwave motion sensor 3pin ASD-09MW	Infrared motion Infrareor 3 pin ASD-09IR ASD-09IR50	Microwave motion sensor smart 3pin ASD-09MW-NLS-WH	Infrared motion sensor smart 3pin ASD-09IR-NLS-WH	Battery back-up kit 20W ASD-EMK20W-WHB5B	Battery back-up kit 30W ASD-EMK30W-WHB5A	Surface mount bracket ASD-SMB1-WHB5	Pendant mounting bracket ASD-PMB1-WHB5	Clear lens 60° for 220W ASD-L60-220-WHB5B	Clear lens 60° for 320W ASD-L60-320-WHB5B
	100W	•	•	•	•	•	•	•	•		
	160W	•	•	•	•	•	•	•	•		
ASD-WHB5B	220W	•	•	•	•	•	•	•	•	•	
	320W	•	•	•	•	•	•	•	•		•
	500W	•	•	•	•	•	•	•	•		
ASD-WHB5B-CP	160W	•	•	•	•						
ADD-WINDDCCP	220W	•	•	•	•					•	

For most up-to-date spec sheets please refer to asd-lighting.com

ASD LIGHTING CORP

E-mail: orders@asd-lighting.com | Web site: www.asd-lighting.com





MOTION SENSOR INFORMATION

REMOTE CONTROL ASD-06RC sold separately

	Button	Remarks	Button	Remarks		Button	Remarks		
·			C Mauntina	Adjust detection area/sensit	ivity levels according to real				
(₩00% (>50%) K2700k(0)30 ⁵	ON/OFF ON/OFF	Turn the sensor ON/OFF.	мн height	installation situations, highe	r or lower.	¢ Up	The main functional buttons to adjust the factors to desired level. Press + - button to dim light directly auto in		
AM DH- ⁰⁴ ☆ 0% SC-01 SK-06 @ 05 XP @ lux	Auto Auto	Enter "sensor mode" and perform previous settings.	send Send	parameters.	previous setting of individual	Down	non-detection mode.		
ОХИ/ОГЕ (М.Н.) (*)	Reset Reset	Enter "sensor mode" and perform the default settings.	Detection range	Also known as "sensitivity", and longest distance. Use th	100 % means the highest sensitivity is button and the + - buttons to adjust.	сст ССТ selectable	Not applicable to this product.		
Auto Send ÷	Scenes Scenes	Shows current settings saved in remote.	Daylight sensor	The preset lux level at which Use this button and the + - b		POWER POWER	Adjust brightness in both ON/OFF mode & sensor mode, minimum 10%, max 100%, each time this button is pressed it changes by 5%.		
Scenes (POWER	Start Start	Press this to begin scene setup.	·ở· Stand-by dimming		dim from 100 % to optional standby ton and the + - buttons to adjust.	Reserved button	Not applicable to this product.		
Start 🔅 🔿	Memory Memory	Saves the scene settings.	🕙 Hold time	The period that light will star is detected. Use this button a	γ illuminated 100 % after no motion and the + - buttons to adjust.	Daylight harvesting	Daylight harvesting function enabled or disabled.		
Appy (B) Test	(Appy) Apply	Applies current scene settings to the fixture.	Stand-by period	The period after holdtime, du dimming level. Use this butt	ring which the light keeps standby on and the + - buttons to adjust.	Test Dutton	Press this button to test the sensor; it will temporarily change the hold time to 2s. This setting cannot be saved.		
		+		+	+				
ASD-09MW Microwave motion sensor 3pin	ASD-06RC Remote control	ASD-09IR ASD-0 Infrared motion Rem sensor 3pin cont	ote Infrare	d motion or 3pin ASD-06RC Remote control		ASD-06RC Remote control or smartphone	ASD-09IR-NLS ASD-06RC Infrared motion sensor smart 3pin or smartphone		
MICROWA	/E MOTIOI	N SENSOR:		IN	FRARED MOTIC	ON SENSO	R:		
8 6 4 2 0 2 4	0 3 6 9 9 12 15 6 8 0 3	9 ft 6 th 3 hi	ighest mounting he (15 m). This figu e maximum dista ghest mounting hei sensitivity. Well detected are Possibly detected	re indicates ance at the ght with 100	22.9 ft 13.1 ft 6.5 ft 0 6.5 ft 13.1 ft 22.9 ft 23.9 ft 23	ft 13.1 ft 6			
Ceiling mounted	Wall mou	unted		Mour	nting height < 39.4 ft (12 m) ceilin	g mounting (* for ASE	0-09IR50 < 49.2 ft (15 m))		
User notes:				U	ser notes:				
		thinner than 0.8" but will be	impaired if thicker t		e driver voltage shall be stable a				
2. The driver voltage s				-	Detection area options may not function as expected because they depend on the Fresnel lens, which provide the provided the pro				
		of motion, mounting height a	nd movement volur		physically determines their operation. 3. Detection distance performance works better when moving parallel to the sensor as opposed to				
 Conduct testing with Dimming performance 			the driver cop't and	to	wards it.				
 Dimming performal OFF, sensor can't ei 		nected to different drivers; If	the driver carrit COP	4.00	onduct testing with adequate aml				
		will be ON 100% for about	10S then dims to s	standby level OF	F, sensor can't either.		ent drivers; If the driver can't completely turn		
				6. Ir or	ie first time powering UN the ser OFF.	isor, light will be UN-I	00% for about 45S then dims to standby level		
Installation precau		ljust sensitivity properly if it's	s installed on side y		stallation precautions:				
it gets more sensitiv		just sensitivity property if its	s moduleu un siue-v	1. Pl	R sensor can't be placed inside a		ns must be completely exposed in air.		
 Make sure the micr 		npletely exposed.			esnel lens of the PIR sensor mus				
		le should be installed facing	the detection area.	3. Su	uitable for ceiling mount installati come more sensitive.	on, adjust sensitivity p	roperly if it's installed on a wall because it will		
Application enviror	ment.								
		ompletely outdoor environ	ment conditions m	night trigger 1. Su	pplication environment: uitable for indoor application, p e sensor.	artial/completely ou	door environment conditions might trigger		

- Keep the sensor module away from AC input and DC output to avoid high/low frequency signal interference.
- 2. The PIR sensor is not suitable for environments with sudden changes in temperature or airflow.
- 3. Not suitable environment if there's shelves between the sensor and target area.
- 4. Shall be mounted securely, to avoid any false triggers caused by movement of the fixture itself.

Specifications	models: ASD-09MW, ASD-09MW-NLS	models: ASD-09IR, ASD-09IR-NLS	models: ASD-09IR50	Default setting		
Detection area	25 %/50 %/75 %/100 %			100 %		
Hold time	Remote control: 5 s/30 s/1 min/3 min/5 min/10 m	in/20 min/30 min Built-in switch: 5 s/1 min/5 min/10 m	nin	10 min		
Daylight threshold	2 lux (0.2 fc)/10 lux (0.9 fc)/30 lux (2.8 fc)/50 lux (4.7	fc)/80 lux (7.4 fc)/120 lux (11.2 fc)/200 lux (18.6 fc)/250 lux (23.2 fc)/ 300 lux (27.9 fc)/350 lux (32.5 fc)/400 lux (37.2 fc)/disable	Disable		
Standby period	0 s/10 s/30 s/1 min/5 min/10 min/30 min/60 min/	+ ∞		0 s		
Standby dimming level	Remote control: 10 %/20 %/30 %/50 % Built-in switch: 0 %/10 %/30 %/50 %					
Operating voltage	10 - 15 V			-		
Operating current	< 30 mA	< 15 mA	< 30 mA	-		
Mounting height	max 49.2 ft (15 m)	max 39.4 ft (12 m)	max 49.2 ft (15 m)	-		
Detection range	≥ 9 ft (3 m)	9.8 - 22.9 ft (3-7 m)		-		
Operating frequency	5.8 GHz ± 75 MHz	-	-	-		
Transmitting power	< 0.3 mW	-	-	-		

For most up-to-date spec sheets please refer to asd-lighting.com

ASD LIGHTING CORP

E-mail: orders@asd-lighting.com | Web site: www.asd-lighting.com

(U) PREM UM

2. Shall be mounted securely, to avoid any false triggers caused by movement of the fixture itself.





For ASD-NLS sensors download ASD NLS app and add the fixture to it according to the manual (download manuals and app from the links or scan the QR codes on the right).



ASD-09MW-NLS Microwave motion sensor smart 3pin



ASD-09IR-NLS Infrared motion sensor smart 3pin















SCHEDULING

Set a variety of customizable start / end actions based



ASD NLS APP download Android

ASD NLS is a professional-grade smart control application designed to manage and control lighting fixtures in commercial properties. With ASD NLS, you can conveniently control your lights

You can group fixtures by rooms, floors and objects, and create schedules based on day and time. You can also grant permanent or temporary permissions to employees and guests with different access levels. Our smart platform enables you to monitor energy usage statistics, view the status of each fixture, and much more.

from your smartphone or PC, anytime and anywhere.







Set brightness, standby time and dimming level,







Give your staff or installers control over the lighting.







Monitor equipment status and receive daily reports.





Create and customize projects for different types of

ADVANCED AREA

MANAGEMENT



Monitor device status and daily reports.



For most up-to-date spec sheets please refer to asd-lighting.com

ASD LIGHTING CORP

E-mail: orders@asd-lighting.com

Web site: www.asd-lighting.com






[®] LED LINEAR HIGH BAY WITH Q-BASE


WITH DUSK/DAWN FUNCTION:

- With insufficient ambient brightness, sensor turns on light and keeps it at standby dimming level even if there is no motion or presence.
- 2. When sensor detects motion or presence it will bring the light level up to 100 %.
- 3. After motion is no longer detected, fixture remains at 100 % for hold time.
- 4. After pre-set hold time period it will dim to standby dimming level again and always keep it.
- 5. With sufficient ambient brightness, sensor will turn OFF light automatically.




WITH DAYLIGHT DISABLED:

- 1. Sensor turns ON light when motion is detected.
- 2. Light will stay on after detecting motion for the desired hold time.
- 3. Sensor dims light to standby dimming level after hold time if there is still no motion.
- 4. Sensor turns OFF light after standby period.



WITH DAYLIGHT THRESHOLD:

- 1. With sufficient daylight, the light remains OFF even after motion is detected.
- 2. With insufficient daylight, the sensor turns light ON when motion is detected.
- 3. After there's no motion detected, the sensor keeps light ON 100 % for holdtime.
- 4. After holdtime, sensor dims light to standby dimming level for standby period. If the standby period has been set as Os, sensor turns light OFF automatically after holdtime.
- The sensor turns OFF light automatically after the standby period when there's no motion detected.



DAYLIGHT HARVESTING:

- When ambient brightness is lower than preset lux level, sensor will turn on light automatically and keep dimming according to the change of the ambient brightness. As it gets darker outside the fixtures will brighten, and as it gets brighter outside the fixtures will dim down.
- 2. When the ambient brightness exceeds the preset lux level, the light will turn OFF.



MICROWAVE MOTION SENSOR:

To avoid blocking the microwave emission, the microwave sensor can not be covered with metal materials, be sprayed with a coating of metal components, or have attached metal material or stickers etc.

The distance between the antenna and the glass (dielectric material) should be no less than 0.4 ft when the sensor is within the glass lampshade. Otherwise, the microwave motion sensor will not penetrate the glass easily.

Avoid placing the sensor inside a metal chamber, this may cause a mis-trigger.


The sensor should not be placed in a small confined space. To avoid increasing the sensor detection range or abnormal operation, the sensor should be kept away from large areas of metal and glass reflectors (separation distance at least 3.3 ft). Reduce the detection area setting.


To avoid affecting the microwave signal transmission, the microwave antenna should be higher than the surrounding metal surface.

Any vibration or movement may trigger the sensor. Ensure the sensor is far from any constant movement.


At least 2 m/6.5 ft distance between microwave sensors;


1.5 m/4.9 ft between the sensor and other wireless devices such as routers to avoid possible radio interference.














sensor 6.5tt sensor 4.9tt routers

DAYLIGHT HARVESTING SETTING:

- 1. Adjust "daylight" value higher than 50lux.
- 2. Preset "standby period" OS.
- **3.** Press "daylight harvesting" button on remote control to activate.

Light OFF Light OFF Daylight harvesting phase Natural light brightness Artificial light brightness

(UL)

For most up-to-date spec sheets please refer to asd-lighting.com

ASD LIGHTING CORP

E-mail: orders@asd-lighting.com | Web site: www.asd-lighting.com



BACK-UP BATTERY KIT INFORMATION

ASD-EMK20W-WHB5B ASD-EMK30W-WHB5A sold separately




Self-check emergency battery back-up kit offers a dependable solution for virtually every LED Linear High Bay lighting application, with options tailored for both new fixture constructions and field installation applications.

A CAUTION:


- Before performing a high-voltage insulation test, ensure the battery pack is removed and that there is no contact between the battery pack and the LED drivers.
- > After testing, disconnect the battery pack unit connector before shipping and storing.
- > During storage, the battery pack will need 24 hours of charging every 3 months.

Specifications	ASD-EMK20W-WHB5B	ASD-EMK30W-WHB5A	STANI
Input voltage	100-347 Vac 50/60 Hz		DISPL
Voltage	120 V		
Output voltage	156 - 230 Vdc	156 - 230 Vdc	Button
Input current	100 mA		
Output current	70 mA		
Power	20W	30W	
Lumen	3,189 lm	4,783 lm	Blir
Emergency time	90 minutes		
Indicator light	Illuminated test switch		👝 Blir
Battery	Li-ion		qui
Charging time	≥ 24 hours		


STANDARD OPERATION DISPLAY STATUS:



WHB5A with battery back-up kit (100-320W)



WHB5A with battery back-up kit (400-500W)



For most up-to-date spec sheets please refer to asd-lighting.com


ASD LIGHTING CORP

E-mail: orders@asd-lighting.com | Web site: www.asd-lighting.com



INSTALLATION STEPS:

- 1. Unscrew and open Battery back-up kit.
- 2. Remove one knockout on the top and one on the side of the driver box. Attach the battery backup kit to the driver box of the fixture with 4 screws.
- 3. Unscrew 4 screws and open driver box of the fixture. Install battery back-up button into the side knockout of the fixture and secure it with washer (included). Then pull the button wire into the battery back-up kit and plug it into the battery controller.
- 4. Connect battery back-up kit to the fixture by:
- a. Pulling the Red wire (DRIVER +) from battery back-up into the fixture and connecting it to the Red wire (Driver output +);
- b. Pull the Black wire (LED- / DRIVER -) from battery back-up into the fixture and connect it with the Black wire (Driver output -), Led1 (input -) and Led2 (-) using one connector (included);
- c. Pull the White wire (LED +) from battery back-up into the fixture and connect it with the Led1 (+) and Led2 (+) using one connector (included);
- 5. Pull the White (N), Black (L), Green (G), Pink (Dim-) and Violet (Dim+) wires from the fixture into the battery back-up kit and connect them with the wires of battery back-up and external power source: Black with Black, White with White, Green with Green, according to the wiring schematic. Use white extension wire (included) if needed. Use pink (Dim-) and violet (Dim+) dimming wires if needed to connect to the dimmer.
- 6. Attach fixture driver box cover with battery back-up kit to the fixture and secure it with screws.



(UL)



INSTALLATION GUIDE

IMPORTANT SAFETY INFORMATION:

Please read all the instructions below before installation!

- Make sure that the supply voltage corresponds to the rated product voltage.
- The product must be installed by a qualified electrician in accordance with the National Electrical Code and corresponding local codes.
- If the product is damaged, do not use it.

▲ WARNING

 ${\rm Risk}$ of personal injury – read and follow all warnings and installation instructions. Keep or give to the owner for future reference.

Risk of cuts: Wear gloves to prevent cuts or abrasions when removing from carton, handling, installing, and maintaining this product.


Risk of electric shock: This product must be installed in accordance with the applicable installation code by a person familiar with the construction and operation of the product and the hazards involved.

 ${\rm Risk}$ of ${\rm Fire:}$ Minimum 194°F supply conductors. Consult a qualified electrician to ensure correct branch circuit conductor.


 $\mathsf{ASD}^{\circledast}$ assumes no responsibility for claims arising out of improper or careless Installation or handling of this product.

INSTALLATION STEPS:

- Insert V-hooks into both ends of the fixture. Secure chain to ceiling, beam or other mounting surface.
- 2. Unscrew and open backplate, use screwdriver to open one knockout.
- 3. Connect the wires: Black to Black, White to White, Green to Green. If you are not using the dimming wires cap them off but not together. Reattach knockout plate to top of the fixture and secure with screw.




POWER AND COLOR TEMPERATURE SETTINGS:



SURFACE MOUNT INSTALLATION:

ASD-SMB1-WHB5 sold separately


- 1. Secure the brackets to ceiling, beam, joist or rail (bolts not included).
- 2. Connect the wires: Black to Black, White to White, Green to Green.
- Attach the fixture to the bracket and secure with one screw per each side of the bracket.



PENDANT MOUNT INSTALLATION:

ASD-PMB1-WHB5 sold separately

- Assemble metal hose with connectors and attach bracket's side plate to one side. Install the bracket on 3/4" NPT pipe. Bracket does not include nuts or screws for mounting to surface.
- 2. Unscrew and take off fixture's backplate, open one knockout using screwdriver. Then attach backplate to free end of the metal hose. Attach the bracket by putting the bracket's hooks into the slots in the center of the housing. Secure the bracket with screws. Connect the wires: Black to Black, White to White, Green to Green.
- Reattach the backplate in its place and secure with screw. Align the studs
 of the side plate with the slots in the housing, place the side plates, and secure them
 with screws.




MOTION SENSOR INSTALLATION:

ASD-09MW ASD-09IR ASD-09IR50

ASD-09MW-NLS ASD-09IR-NLS

sold separately

- 1. Unscrew the microwave sensor base cap.
- Insert and twist the sensor until it is tight on the base surface.



(UL)

For most up-to-date spec sheets please refer to asd-lighting.com

ASD LIGHTING CORP

E-mail: orders@asd-lighting.com | Web site: www.asd-lighting.com





[®] LED LINEAR HIGH BAY WITH Q-BASE

ORDERING INFORMATION

Model	Product dimensions	Weight	Pcs. per carton	Carton size	Carton weight	UPC		
	WHB5B 150lm/W							
ASD-WHB5B-100A50	14-15/16" x 9-13/16" x 2-15/16"	4.1 lbs (1.9 kg)	1	15.9" x 10.6" x 3.7"	5.5 lbs	810128116817		
ASD-WHB5B-160A50	14-15/16" x 9-13/16" x 2-15/16"	5 lbs (2.3 kg)	1	15.9" x 10.6" x 3.7"	6.4 lbs	810128116510		
ASD-WHB5B-220A50	17-11/16" x 12-7/16" x 2-15/16"	7 lbs (3.2 kg)	1	18.7" x 13.2" x 3.7"	8.8 lbs	810128116527		
ASD-WHB5B-320A50	20-1/2" x 14-7/16" x 3-1/4"	9.2 lbs (4.2 kg)	1	21.5" x 15.2" x 4"	11.2 lbs	810128116534		
ASD-WHB5B-500A50	35-1/2" x 12-7/16" x 2-15/16"	14.2 lbs (6.4 kg)	1	36.5" x 13.2" x 3.7"	17.5 lbs	810128116565		
	W	HB5B-CP 150lm/W +10ft	CORD WITH PLUG					
ASD-WHB5B-160A50-CP	14-15/16" x 9-13/16" x 2-15/16"	6.3 lbs (2.8 kg)	1	15.9" x 10.6" x 4.3"	7.3 lbs	810128118538		
ASD-WHB5B-220A50-CP	17-11/16" x 12-7/16" x 2-15/16"	8.3 lbs (3.8 kg)	1	18.7" x 13.2" x 4.3"	9.7 lbs	810128118545		

ACCESSORIES:

Model	Product dimensions	Pcs. in middle box	Middle box size	Middle box weight	Pcs. per carton	Carton size	Carton weight	UPC	GTIN 14 in middle box	GTIN 14 in carton
ASD-09MW-WH	2-1/8" x 2-1/8" x 1-5/16"	10	5.5" x 2.6" x 11.4"	1.2 lbs	120	17.3" x 11.8" x 11"	12.1 lbs	810128113700	20810128113704	30810128113701
ASD-09MW-BK	2-1/8" x 2-1/8" x 1-5/16"	10	5.5" x 2.6" x 11.4"	1.2 lbs	120	17.3" x 11.8" x 11"	12.1 lbs	810128113717	20810128113711	30810128113718
ASD-09IR-WH	2-1/8" x 2-1/8" x 1-11/16"	10	5.5" x 2.6" x 11.4"	1.2 lbs	120	17.3" x 11.8" x 11"	12.1 lbs	810128113694	20810128113698	30810128113695
ASD-09IR-BK	2-1/8" x 2-1/8" x 1-11/16"	10	5.5" x 2.6" x 11.4"	1.2 lbs	120	17.3" x 11.8" x 11"	12.1 lbs	810128114349	20810128114343	30810128114340
ASD-09IR50-WH	2-1/8" x 2-1/8" x 1-11/16"	10	5.5" x 2.6" x 11.4"	0.9 lbs	120	17.3" x 11.8" x 11"	10.7 lbs	810128116794	10810128116791	20810128116798
ASD-09MW-NLS-WH	2-1/8" x 2-1/8" x 1-3/8"	10	5.5" x 2.6" x 11.4"	1.2 lbs	120	17.3" x 11.8" x 11"	12.1 lbs	810128113762	20810128113766	30810128113763
ASD-09IR-NLS-WH	2-1/8" x 2-1/8" x 1-11/16"	10	5.5" x 2.6" x 11.4"	1.2 lbs	120	17.3" x 11.8" x 11"	12.1 lbs	810128113755	20810128113759	30810128113756
ASD-06RC	5-11/16" x 1-3/4" x 13/16"	10	6.3" x 2.9" x 11.4"	0.5 lbs	60	15.8" x 11.8" x 9.3"	24.7 lbs	810128114370	30810128114371	40810128114378
ASD-EMK20W-WHB5B	9-5/8" x 4-5/8" x 1-7/8"	-	-	-	10	10.5" x 10.2" x 11.5"	26.5 lbs	810128113977	-	10810128113974
ASD-EMK30W-WHB5A	9-5/8" x 4-5/8" x 1-7/8"	-	-	-	10	10.5" x 10.2" x 11.5"	26.5 lbs	810050735933	-	10810050735930
ASD-SMB1-WHB5	4" x 3-11/16" x 3-1/16"	-	-	-	50	22.8" x 7.9" x 20.9"	24.3 lbs	810050739764	-	20810050739768
ASD-PMB1-WHB5	4" x 3-11/16" x 3-1/8"	-	-	-	50	22.8" x 7.9" x 20.9"	34.2 lbs	810050739757	-	20810050739751
ASD-L60-220-WHB5B	17-9/16" x 3-7/8" x 3/8"	-	-	-	20	18.4" x 8.5" x 6.6"	16 lbs	810128118491	-	20810128118495
ASD-L60-320-WHB5B	20-5/16" x 4-13/16" x 3/8"	-	-	-	20	21.2" x 10.3" x 6.6"	23.4 lbs	810128118507	-	20810128118501

ANNEX 1

Model	Watts	5,000 K
	60W	10,148 lm
ASD-WHB5B-100A50	80W	12,805 lm
	100W	15,386 lm
	100W	16,882 lm
ASD-WHB5B-160A50 ASD-WHB5B-160A50-CP	130W	20,567 lm
	160W	24,842 lm
	130W	22,574 lm
ASD-WHB5B-220A50 ASD-WHB5B-220A50-CP	160W	27,067 lm
A3D-W11D3D-220A30-CI	220W	35,342 lm
	160W	29,052 lm
ASD-WHB5B-320A50	220W	38,111 lm
	320W	50,848 lm
	320W	53,174 lm
ASD-WHB5B-500A50	400W	63,909 lm
	500W	75,905 lm

For most up-to-date spec sheets please refer to asd-lighting.com

U

DLC

PREMIUM

ASD LIGHTING CORP

 $\Delta \perp \perp$

E-mail: orders@asd-lighting.com | Web site: www.asd-lighting.com

1X -S